

SPARE PARTS LIST
ELECTRIC WATER HEATER GEYSER
Models

SG 50 2,5 K

SG 80 2,5 K


SG 100 2,5 K

SG 80 TD 2,5 K

SG 100 TD 2,5 K

Edition 1 of 1 April 2001





MODELS	CODE	SERIAL NO. VALIDITY	REF.
SG 50 2,5 K	869686	010301	A
SG 80 2,5 K	869687	010301	B
SG 100 2,5 K	869688	010301	C
SG 80 TD 2,5 K	869691	010301	D
SG 100 TD 2,5 K	869692	010301	E

PART.	CODE	DESCRIPTION	REF.	NOTE
1	571731	Thermometer		
2	993014	Anode (magnesium 25 x 230)		
3	816630	Element RCA 300 PA M5 (2500W-230V)		
4	993012	Flange with gasket		
5	993000	Wood Screw (thread M6x14 8mm)		
6	993011	Flange bracket		
7	993004	Terminal shield (grey)		
8	570127	M8x14x8 hexagonal nut		
9	993186	Signal lamp		
10	691214	Thermostat (TBS 2 300)		
11	993180	Plastic cover		
12	571730	Safety valve		

NOTE	DESCRIPTION
-------------	--------------------